

[Cedrus](#)[Products](#)[Ordering](#)[Support](#)[XID Home](#)[Device Properties](#)[Timing Features](#)[Supported Protocols](#)[Accessory Connector](#)[Voice Key](#)[Test Procedures](#)[Misc. Commands](#)

XID Accessory Connector Command

Get Battery Level (_f8)

What it Does

Returns the battery voltage level on battery-operated XID devices.

Using This Command

Send bytes **_f8**.

Corresponding Inquiry Command

This command has no inquiry equivalent.

© Copyright 2014 **Cedrus Corporation**, P.O. Box 6309, San Pedro, CA 90734 - USA

Toll Free: (800) 233-7871, other: (310) 548-9595. Send us [an email](#) or join [mailing list](#). 