

[XID Home](#)[Device Properties](#)[Timing Features](#)[Supported Protocols](#)[Accessory Connector](#)[Voice Key](#)[Test Procedures](#)[Misc. Commands](#)

XID Accessory Connector Command

Set Debounce Time (a6)

What it Does

Sets the debouncing period for those I/O lines that are designated as input. This command affects the XID device's behavior only when the Accessory Connector [mode](#) is set to General Purpose and some lines have been set as input by the [Set I/O Direction](#) command.

Factory default is zero milliseconds.

Using This Command

Send bytes **a6** followed by a single byte indicating the debouncing period in milliseconds.

Corresponding Inquiry Command

Send bytes **_a6**. The XID device returns **_a6** followed by a single byte indicating the debouncing period.