

[Cedrus](#)[Products](#)[Ordering](#)[Support](#)[XID Home](#)[Device Properties](#)[Timing Features](#)[Supported Protocols](#)[Accessory Connector](#)[Voice Key](#)[Test Procedures](#)[Misc. Commands](#)

XID Accessory Connector Command

Set Pulse Duration (ap)

What it Does

Sets the pulse duration in milliseconds. This command affects the XID device's behavior only when the Accessory Connector **mode** is set to "Reflective, Single Pulse" or "Reflective, Double Pulse".

Factory default is 10 milliseconds.

Using This Command

Send bytes **ap** followed by one byte indicating the pulse duration in milliseconds.

Corresponding Inquiry Command

Send bytes **_ap**. The XID device returns **_ap** followed by one byte indicating the pulse duration in milliseconds.

© Copyright 2014 **Cedrus Corporation**, P.O. Box 6309, San Pedro, CA 90734 - USA

Toll Free: (800) 233-7871, other: (310) 548-9595. Send us [an email](#) or join [mailing list](#). 